

# Creating and Deleting Relationship Types

Beginning with version 7.0, RiskVision provides the ability to create and delete a relationship type when `com.agilience.asset.enableCreateRelationshipTypes=true` property is added to the `agilience.properties` file. You can only delete the relationship types you have created, if the relationship type is not in use.

## To create a new relationship type

1. In the RiskVision application, go to **Configuration > Entity Configuration**. The **Relationships** tab details are displayed.
2. Click **New**. The **Create New Relationship** dialog appears.
3. In the dialog, enter the following fields.
  - **Relationship Name**. Name of the relation between entities
  - **Inverse of Relationship**. Name of the reverse relation
  - **Description**. Information that helps demonstrate the purpose of creating the relationship type
4. Click **OK**. The new relationship type is created.

User-defined relationship type allows the establishment of the relation only between the entities.

## To delete a relationship:

1. In the RiskVision application, go to **Configuration > Entity Configuration**. The **Relationships** tab details are displayed.
2. In the **Relationships** tab, select the custom relationship type that is not in use, and click **Delete**. The relationship is deleted